



QUICK START GUIDE

Getting Started

1. Position The Gun 14X under the basket.
2. Complete machine setup using the instructions located on the back of the machine.
3. Hang the makes counter on the back of the rim.
4. Plug the machine into a 120-volt outlet.
5. Turn on the power switch near the power cord.
6. Allow approximately 20 seconds for startup.
7. Follow the touchscreen prompts to complete registration.
8. Tap **Shoot Now**
9. Select shooting locations
10. Press **Start**

Warning: Do not connect multiple extension cords. Using multiple cords may damage the motor.

Need Help?

Shoot-A-Way Customer Service is available Monday through Friday, 9:00 AM–5:00 PM EST.

Website: www.shootaway.com

Phone: 800-294-4654

Email: sales@shootaway.com

[Setup Videos & Full Instruction Manuals](#)

