


# To Program Remote Control



To program the remote on the Gun 8000

1. - With the power off, press and hold the Pre-Programmed Drills button.
2. - Toggle the Power button to the On ( I ) position. The digital display will display LL and then start counting down from 15. After the power is on and the countdown has started, release the Pre-Programmed Drills button.
3. Press any button on the remote transmitter while the display is counting down.

Remote is ready to use.

**Please call with any Questions or Problems  
800-294-4654**